





- ✓ Do not position yourself between overhead hazards, such as joists and beams, and the rails of the basket.
- ✓ Know that movement of the lift could crush the worker(s).
- ✓ Maintain a minimum clearance of at least 20 feet away from the nearest energized overhead lines, UNLESS a permit has been developed & issued.
- ✓ Treat power lines, wires and other conductors as energized, even if they are down or appear to be insulated.

